



WT = WIDTH OF TURN LANE ADDED
 L = LENGTH OF TAPER

NOTES:

1. SEE ENGINEER FOR POCKET LENGTH.
2. SEE SECTION 3.2.3.2 FOR MINIMUM TAPER LENGTH.



NONCONTINUOUS LEFT TURN LANE

DRAWING NUMBER	CH-190-1
SCALE	NONE
REVISION DATE	2/24
DEPARTMENT	TRANS