



PLAN

NOTES:

1. SEE COB STD. DWG. PK-IM-07G FOR TYPICAL SOIL CELL SECTION AND ADDITIONAL SOIL CELL NOTES.
2. AIR AND WATER SYSTEM CAN BE USED WHEN SOIL CELLS DO NOT HAVE DRIP IRRIGATION OR ARE UNDER IMPERVIOUS PAVEMENT. LAY OUT PIPE AND VENTS IN A STRAIGHT LINE FOR PIPE MAINTENANCE CLEANING.
3. TOPSOIL PER COB STD. DWG. SW-130-1. TOPSOIL TO BE PLACED IN SOIL CELLS PER SOIL CELL MANUFACTURER'S SPECIFICATIONS.



City of Bellevue

TITLE:

PLANTING - R.O.W. TREE WITH SOIL CELLS PLAN

DRAWING #:	PK-IM-07F
SCALE:	N.T.S.
REVISION DATE:	08-2020
DEPARTMENT:	PARKS



Standard detail revised with support of King Conservation District