



TYPE 2 PREPARATION SEQUENCE:

STEP	DESCRIPTION
1	EXCAVATE EX SOIL TO 18" MIN. DEPTH BELOW FINISH GRADE. AVOID UNDERMINING NEARBY FEATURES.
2	INSTALL 3" DEPTH FINE COMPOST.
3	SCARIFY TOPSOIL TO A 9" DEPTH. ENGINEER SHALL REVIEW & APPROVE SCARIFICATION PRIOR TO PROCEEDING TO STEP 4.
4	INSTALL 15" MIN. DEPTH TOPSOIL TYPE A AND REVIEW FINISH GRADE WITH ENGINEER PRIOR TO PLANTING.
5	INSTALL PLANTS, MATERIALS & IRRIGATION PER SPECIFICATIONS.
6	INSTALL 1/2" DEPTH MULCH PER SPECIFICATIONS (NO WOOD CHIPS)

NOTES:

1. ALL DIMENSIONS INDICATE COMPACTED DEPTHS. TOPSOIL TYPE A & MULCH SHALL BE COMPACTED TO 85% DRY DENSITY.
2. INCREASE DEPTH OF EXCAVATION & TOPSOIL TO ACCOMODATE TREE ROOT BALL DEPTHS OF 18"-30".
3. MOUND TOPSOIL IN PLANTER STRIPS AND MEDIANS PER SPECIFICATIONS.



City of
Bellevue

TITLE:

**PLANTING - STREETSCAPE MEDIANS - TYPE 2
SOIL PREPARATION**

DRAWING #:	PK-IM-06C
SCALE:	N.T.S.
REVISION DATE:	12-2018
DEPARTMENT:	PARKS